



Top View

Bottom View

Collapse the Boot Seal



Top View



Bottom View

Attach Boot Seal to Mandrel



Polylok Boot Seal properly installed.