



3 Fairfield Boulevard, Wallingford, Connecticut 06492
Office: 1-877-765-9565 Fax: 203-284-8514
email: sales@polylok.com
Web site: www.polylok.com

Polylok Insulation Instructions

Polylok riser insulation can be pressed into the underside of the riser openings to provide the cover with R-10 insulation value. Some installations may require more secure bonding, follow the instructions below.

Polylok riser insulation can be glued to the riser underside with 3M Fastbond Contact Adhesive 30 N-F to provide a secure bonding of insulation to the riser cover. This is a water base adhesive that dries in 30 minutes. Apply to the ribs of the riser & press insulation into the ribs until secure.

If a faster drying time is required use 3M Scotch-Weld Neoprene High Performance Contact Adhesive. This solvent based product works well on insulation material.

For questions on our Polylok products please call:

1-877-765-9565

7:30 am – 6:00 pm EST