

5-11/16 INLET

7-11/16 FILTER OUTLET

USE 5" HOLE SAW
(FOR 4" PIPE GROMMET)

POLYLOK FILTER CHAMBER
INSTRUCTIONS FOR INLET-OUTLET CUTOUTS

1. LOCATE AND MARK CENTERS FOR INLET AND OUTLET AS SHOWN IN DRAWING ABOVE
2. DRILL 1/4" HOLE AT THE 2 LOCATIONS
3. USING 5" HOLE SAW WITH 1/4" PILOT PIN DRILL 5" HOLES
4. INSTALL 4" GROMMET IN OPENINGS
5. GREASE GROMMET AND INSTALL PIPE
6. USING SOLVENT CEMENT INSTALL FILTER HOUSING ONTO OUTLET PIPE