

Polylok Handle & Receiver Installation

Method #1

Polylok handles can be installed in concrete tank covers by placing a piece of # 3 rebar 6.5 inches long through the handle holes. Insert the handle into the concrete up to the horizontal taps on the vertical sides of the handle. The handle and rebar will require a set time of 24 hrs. and full cure on the concrete of 28 days. Handle # 3551, 240 per case quantity. Handle material is HDPE.

Method #2

Polylok handles can be installed in concrete tank covers by placing a piece of # 3 rebar 6.5 inches long through the handle holes and receiver tray. The receiver tray allows the handle to pivot on # 3 rebar and fold down flush with the covers surface. The receiver tray must be inserted with the L-shaped wing on the front of the receiver tray first as this will prevent the tray from floating. The handle, receiver and rebar will require a set time of 24 hrs. and full cure on the concrete of 28 days. Receiver # 3047-REC, 240 per case quantity on both. Receiver material is Polypropylene.

Cover removal

Cover removal with Polylok handles and receivers requires covers to be first loosened with a pry bar by tapping the cover to loosen it. The recommended way to remove covers with handles is to use a 2 inch strap around the pry bar and through the handle. This method prevents damaging the handles or receivers.

Note: Don't use a prybar directly on the handles or receivers or connect chains to a bucket loader & handle for removal.