



INSTRUCTIONS FOR INSTALLING POLYLOK 24" RISER ADAPTER ONTO IPEX PIPE

- 1 - CUT IPEX PIPE TO DESIRED LENGTH BEING CAREFUL TO MAKE A SMOOTH END FLAT CUT AS POSSIBLE.
- 2 - APPLY POLYLOK ADHESIVE PL-E6100 OR EQUIVALENT ADHESIVE/SEALANT TO BOTH MATING SURFACES.
- 3 - USING STAINLESS STEEL SCREWS, FASTEN POLYLOK 24" RTR TO THE TOP OF THE IPEX PIPE. USE THE 8 SLOTS CLOSEST TO THE CENTER (SEE ENLARGED VIEW)
- 4 - THE POLYLOK 24" RTR WILL ACCEPT ALL 24" DIAMETER PRODUCTS. INCLUDING ALL COVERS, RISERS AND SAFETY SCREENS.

24" RTR
PART NO. 3009-RTR24

USE POLYLOK ADHESIVE
PART NO. PL-E6100
OR SEALANT
ON THESE SURFACES

24" IPEX PIPE

USE THE 8 SLOTS CLOSEST
TO THE CENTER (NOT MARKED)
TO FASTEN

