



10 - #14X 1 1/4" SS PHILLIPS HEAD SCREWS

POLYLOK RISER TO RISER RING
PART NO. 3009-RTR24

USE ONLY THE OUTSIDE
HOLES IN RTR RING

SCREWS MUST BE FASTENED
ONLY IN SLOTS ON ISI RING

ISI 1500 SEALANT OR EQUIVALENT
MUST BE APPLIED ON THIS ENTIRE
SURFACE PRIOR TO INSTALLATION

BUTYL SEALANT CAN ALSO BE
PROVIDED A 50% EVEN COMPRESSION
IS USED

**INSTRUCTIONS FOR INSTALLING THE POLYLOK
3009-RTR24 RISER TO RISER (RTR) RING
TO AN INFILTRATOR SYSTEMS (ISI) TANK**

1. APPLY ISI 1500 SEALANT OR EQUIVALENT TO THE ENTIRE SURFACE ON THE ISI RING IN THE DIAGRAM.

NOTE: IF BUTYL SEALANT IS USED, BUTYL MUST BE COMPRESSED AT LEAST 50%.

2. ALIGN THE OUTSIDE HOLES IN THE RTR RING WITH THE SLOTS PROVIDED IN THE ISI RING.

3. USING 10 - #14 x 1/4" PHILLIPS HEAD STAINLESS SCREWS START ALL 10 SCREWS IN THEIR LOCATIONS. IT IS IMPORTANT TO TIGHTEN ALL 10 SCREWS IN A "STAR" PATTERN. THIS WILL PROVIDE EVEN DISTRIBUTION OF THE SEALANT OR BUTYL.

DO NOT OVER TIGHTEN THE SCREWS. THIS WILL CAUSE DISTORTION OF THE RTR RING

ISI TANK RING