



24" PVC RIBBED PIPE

PLASTIC PIPE KIT



- 8 - #10 x 1" HEX DRIVE SCREWS
- 6 - #10 X 3/4" PHILLIPS PAN HEAD SCREWS



24" HDPE CORRUGATED PIPE

CONCRETE PIPE KIT

- 8 - 1/4" x 1 1/2" WEDGE ANCHORS
- 6 - #10 X 3/4" PHILLIPS PAN HEAD SCREWS
- 1/4" MASONRY BIT




24" CONCRETE RISER

INSTRUCTIONS FOR INSTALLING THE POLYLOK 24" SAFETY SCREEN FOR PIPE AND CONCRETE RISERS PART NO'S 3008-RSSPIPE AND 3008-RSSCONC

1. FULLY COLLAPSE LEDGE RING BY RELEASING TAB ON RATCHET CATCH (AS IN FIGURE 1).
2. INSTALL LEDGE RING INTO PIPE OR RISER. MAKE SURE LEDGE FACES UP AND IS AT LEAST 7" BELOW TOP OF PIPE OR RISER.
3. EXPAND LEDGE RING TO PROVIDE A TIGHT FIT WITH THE ID OF PIPE OR RISER. INSTALL IT AT LEAST 7" DOWN FROM THE TOP OF RISER OR PIPE.
4. FOR RIBBED AND CORRUGATED PIPE, USE A POWER DRILL DRIVER WITH 5/16" HEX DRIVE BIT. SECURE LEDGE RING TO PIPE THRU HOLES IN LEDGE RING WITH 8 - #10 x 1" HEX HEAD SCREWS PROVIDED.
- 4A. FOR CONCRETE RISER INSTALLATION. USING SUPPLIED 1/4" MASONRY BIT REDRILL LEDGE RING AND CONTINUE TO DRILL 1" INTO CONCRETE RISER. INSTALL THE 8 SUPPLIED WEDGE ANCHORS.
5. INSTALL THE SAFETY SCREEN USING 6 SUPPLIED #10 X 3/4" PHILLIPS PAN HEAD SCREWS.

NOTE: ALL 6 SCREWS MUST BE USED TO SECURE SAFETY SCREEN TO LEDGE RING.



8 - #10 x 1" STAINLESS STEEL HEX DRIVE SCREWS USED TO FASTEN LEDGE RING TO PIPE (8 - 1/4" x 1 1/2" WEDGE ANCHORS FOR CONCRETE RISERS)

